

Top of ring should not be less than  $\frac{3}{32}$ " above bottom of lifting head feather valve when valve is adjusted for use

Machine  
Angle on Base  $46^\circ$   
Angle on Valve  $45^\circ$

